



Dimensions and arrangement of right angle brackets (mm)




Right angle brackets mounting on NCS125T sensors



NCS traction current sensors

Fixed installations

Dimensions and arrangement of right angle brackets (mm)



Right angle brackets mounting on NCS125T sensors

